

PEARL Reconditioning Standards			
MEDIUM VOLTAGE AIR DISCONNECT SWITCHES ENCLOSED MANUALLY OPERATED NON-FUSIBLE	Revision		
	Standard	Number	Date
	2110	5	11-2008

The term "reconditioning" is defined as "the process of returning electrical equipment to safe and reliable operating condition based on the design of the original manufacturer at the time of manufacturing."

REFERENCES

The following references are use in this standard. Each of these references can be found in their respective listed locations.

Table References: Section 6000

- Table 1: US Standard bus connection bolt torque values.
- Table 2: Insulation resistance and test values for electrical apparatus.
- Table 11: Insulation resistance and test temperature conversion to 20°C values.

I TEST EQUIPMENT

The following test equipment is required to perform the testing requirements of this reconditioning standard:

1. Insulation Resistance Test Set (Megohmmeter) 2500 Vdc minimum
2. DC Overpotential Test Set (Hipot)

One of the following pieces of test equipment is required to perform the contact resistance testing requirements of this reconditioning standard:

1. Digital Low Resistance Ohmmeter (DLRO – 10 amp unit is sufficient.)
2. DC Current Source and a Millivoltmeter

PEARL Reconditioning Standards			
MEDIUM VOLTAGE AIR DISCONNECT SWITCHES ENCLOSED MANUALLY OPERATED NON-FUSIBLE	Revision		
	Standard	Number	Date
	2110	5	11-2008

II RECONDITION EVALUATION

These steps are used to determine what will be required to recondition this product under this standard.

INSPECTION

1.1 Frame/Enclosure

- 1.1.1 Ensure that the nameplate data is legible.
- 1.1.2 Ensure that the third party listing service label is legible.
- 1.1.3 Inspect for missing screws, bolts, nuts, fasteners, retainers and keepers.
- 1.1.4 Inspect for rust and corrosion.
- 1.1.5 Inspect all insulators for defects, cracks, chips and signs of tracking.
- 1.1.6 Inspect insulation structure for signs of overheating and deterioration.
- 1.1.7 Inspect viewing window for cracks and clarity.
- 1.1.8 Inspect glass weather stripping.
- 1.1.9 Record results on an approved PEARL Evaluation Form.

1.2 Interlocks

- 1.2.1 Inspect for proper door interlock operation.
- 1.2.2 Inspect for proper Kirk lock assembly, if necessary.
- 1.2.3 Record results on an approved PEARL Evaluation Form..

1.3 Interphase Barriers

- 1.3.1 Inspect for dust, dirt and foreign materials.
- 1.3.2 Inspect for chips, cracks and deterioration.
- 1.3.3 Inspect for overheating and tracking.
- 1.3.4 Record results on an approved PEARL Evaluation Form.

1.4 Arc Extinguishers

- 1.4.1 Inspect for loose and missing parts.
- 1.4.2 Inspect for dust, dirt, foreign material, cracks, chips and signs of overheating.
- 1.4.3 Inspect for excessive deterioration and carbon buildup.
- 1.4.4 Inspect arc runners for excessive deterioration.
- 1.4.5 Record results on an approved PEARL Evaluation Form.

1.5 Arcing Contacts or Blades

- 1.5.1 Inspect for excessive deterioration.
- 1.5.2 Inspect for cracks, chips and pitting.
- 1.5.3 Inspect for signs of overheating.
- 1.5.4 Record results on an approved PEARL Evaluation Form.

1.6 Main Contacts or Blades

- 1.6.1 Inspect for excessive deterioration.
- 1.6.2 Inspect for cracks, chips and pitting.
- 1.6.3 Inspect for signs of overheating.
- 1.6.4 Record results on an approved PEARL Evaluation Form.

PEARL Reconditioning Standards			
MEDIUM VOLTAGE AIR DISCONNECT SWITCHES ENCLOSED MANUALLY OPERATED NON-FUSIBLE	Revision		
	Standard	Number	Date
	2110	5	11-2008

1.7 Operating Mechanism

- 1.7.1** Inspect for signs of rust and corrosion.
- 1.7.2** Inspect for excessive and inappropriate lubrication.
- 1.7.3** Inspect closing spring.
- 1.7.4** Inspect opening spring.
- 1.7.5** Inspect operating chain and belt.
- 1.7.6** Inspect for missing screws, bolts, nuts, fasteners, retainers and keepers.
- 1.7.7** Manually operate disconnect switch a minimum of five (5) times while checking for proper operation of the quick-make and quick-break feature.
- 1.7.8** Record results on an approved PEARL Evaluation Form.

PEARL Reconditioning Standards			
MEDIUM VOLTAGE AIR DISCONNECT SWITCHES ENCLOSED MANUALLY OPERATED NON-FUSIBLE	Revision		
	Standard	Number	Date
	2110	5	11-2008

2 TESTING

2.1. Insulation Resistance

2.1.1 Perform an insulation resistance test at test values specified in Table 2 of Section 6000 as follows:

2.1.1.1 Disconnect switch in the open position (unless a visual open air gap exist)

2.1.1.1.1 Line to load

2.1.1.2 Disconnect switch in the closed position

2.1.1.2.1 Phase to phase

2.1.1.2.2 Phase to ground

2.1.2 Correct for temperature, if necessary (Table 11).

2.1.3 Record results on an approved PEARL Evaluation Form.

2.1.4 Compare test results to manufacturer's recommendations or Table 2 of Section 6000.

2.2 Contact Resistance

2.2.1 Perform a contact resistance, millivolt drop test or watt-loss test from line to load on each phase of a closed switch with the test points at the line and load lug landings.

2.2.2 Record results on an approved PEARL Evaluation Form.

2.2.3 Compare test results to manufacturer's recommendations.

2.2.4 A PEARL recognized method is comparing the test results of each pole. Results should be within 50% for any of the poles. Any industrial standard used shall provide at least the same integrity as the PEARL recognized standard of comparing the test results of each pole and ensuring that they are within 50% of each other.

PEARL Reconditioning Standards			
MEDIUM VOLTAGE AIR DISCONNECT SWITCHES ENCLOSED MANUALLY OPERATED NON-FUSIBLE	Revision		
	Standard	Number	Date
	2110	5	11-2008

III RECONDITIONING PROCEDURES

The following procedures are in a recommended order and are required to recondition this product. PEARL recognizes that, based on actual product design and as found condition, some of these procedures may not be applicable. The testing requirement must be completed before the product can be labeled as a PEARL reconditioned product.

1 RECONDITIONING

1.1 Frame/Enclosure

- 1.1.1 Disassemble to clean.
- 1.1.2 Clean all parts of contamination and corrosion.
- 1.1.3 Prepare the frame/enclosure to paint, as necessary.
- 1.1.4 Paint frame/enclosure.

1.2 Missing or Defective Components, Parts and Hardware

- 1.2.1 Replace or repair any missing or defective components, parts and hardware found during the inspection phase of this standard.

1.3 Operating Mechanism

- 1.3.1 Disassemble operating mechanism, as necessary.
- 1.3.2 Clean operating mechanism.
- 1.3.3 Replace any defective parts.
- 1.3.4 Replate operating mechanism parts, as necessary.
- 1.3.5 Assemble operating mechanism.
- 1.3.6 Apply proper lubrication.
- 1.3.7 Manually operate disconnect switch a minimum of ten (10) times while checking for proper operation of the quick-make and quick-break feature.

1.4 Arc Extinguishers

- 1.4.1 Remove arc extinguishers.
- 1.4.2 Clean arc extinguishers.
- 1.4.3 Replace any defective arc extinguishers.
- 1.4.4 Assemble arc extinguishers.

1.5 Arcing Contacts or Blades

- 1.5.1 Remove and replace any defective arcing contacts/blades.
- 1.5.2 Stationary arcing contacts.
 - 1.5.2.1 Clean and dress.
 - 1.5.2.2 Remove and replate, as necessary.
 - 1.5.2.3 Replace contacts.
- 1.5.3 Movable arcing contacts or blades.
 - 1.5.3.1 Clean and dress.
 - 1.5.3.2 Remove and replate, as necessary.
 - 1.5.3.3 Replace contacts or blades.
- 1.5.4 Check for proper wipe and alignment.
- 1.5.5 Check for proper torque on connections.

PEARL Reconditioning Standards			
MEDIUM VOLTAGE AIR DISCONNECT SWITCHES ENCLOSED MANUALLY OPERATED NON-FUSIBLE	Revision		
	Standard	Number	Date
	2110	5	11-2008

1.6 Main Contacts or Blades

1.6.1 Remove and replace any defective main contacts.

1.6.2 Stationary main contacts.

1.6.2.1 Clean and dress.

1.6.2.2 Remove and replate, as necessary.

1.6.2.3 Replace contacts.

1.6.3 Movable main contacts or blades.

1.6.3.1 Clean and dress.

1.6.3.2 Remove and replate, as necessary.

1.6.3.3 Replace contacts or blades.

1.6.4 Check for proper wipe and alignment.

1.6.5 Check for proper torque on connections.

1.7 Current Carrying Components

1.7.1 Hinge/pivot joints.

1.7.1.1 Clean and degrease.

1.7.1.2 Replate, as necessary.

1.8 Checks and Adjustments

1.8.1 Arcing contacts or blades

1.8.1.1 Check and adjust for proper wipe, pressure and gap.

1.8.1.2 Check and adjust for proper alignment/seating in the closed position.

1.8.1.3 Check and adjust for proper sequence.

1.8.2 Main contacts or blades

1.8.2.1 Check and adjust for proper wipe, pressure and gap.

1.8.2.2 Check and adjust for proper alignment/seating in the closed position.

1.8.2.3 Check and adjust for proper sequence.

1.8.3 Hinge/Pivot

1.8.3.1 Check for proper adjustment based on manufacturer's recommendations.

1.8.4 Make all checks and adjustments per manufacturer's instructions. In the absence of a manufacturer's instructions, these adjustments will be based on procedures that will ensure that the original manufacturer's design.

1.9 Torque

1.9.3 Check all screw and bolt connections for the proper torque per manufacturer's recommendations or industrial standards (Table 1).

1.9.4 Record results on an approved PEARL Reconditioning Test Form.

1.10 Final Assembly

1.10.3 Ensure that the frame/enclosure is plumb and square.

1.10.4 Cover any unused openings.

1.10.5 Ensure that the nameplate/label data is complete, correct and legible.

PEARL Reconditioning Standards			
MEDIUM VOLTAGE AIR DISCONNECT SWITCHES ENCLOSED MANUALLY OPERATED NON-FUSIBLE	Revision		
	Standard	Number	Date
	2110	5	11-2008

2 TESTING

2.1 Insulation Resistance

2.1.1 Perform an insulation resistance test at test values specified in Table 2 of Section 6000 as follows:

2.1.1.1 Disconnect switch in the open position (unless a visual open air gap exist)

2.1.1.1.1 Line to load

2.1.1.2 Disconnect switch in the closed position

2.1.1.2.1 Phase to phase

2.1.1.2.2 Phase to ground

2.1.2 Correct for temperature, if necessary (Table 11).

2.1.3 Record results on an approved PEARL Reconditioning Test Form.

2.1.4 Compare test results to manufacturer's recommendations or Table 2 of Section 6000.

2.1.5 The test results must be within the guidelines recommended in order for the product to become a PEARL labeled product.

2.2 Overpotential Test

2.2.1 Perform an overpotential test at test voltage specified in Table 5 of Section 6000 as follows:

2.2.1.1 Disconnect switch in the open position (unless a visual open air gap exists)

2.2.1.1.1 Line to load

2.2.1.2 Disconnect switch in the closed position

2.2.1.2.1 Phase to phase

2.2.1.2.2 Phase to ground

2.2.2 Record results on an approved PEARL Reconditioning Test Form.

2.2.3 Compare results to manufacturer's recommendations or industrial standards.

2.2.4 The test results must be within the guidelines recommended in order for the product to become a PEARL labeled product.

2.3 Contact Resistance

2.3.1 Perform a contact resistance, millivolt drop test and/or watt-loss test from line to load on each phase of a closed switch as follows:

2.3.2 Record results on an approved PEARL Reconditioning Test Form.

2.3.3 A PEARL recognized method is comparing the test results of each pole. Results should be within 50% for any of the poles. Any industrial standard used shall provide at least the same integrity as the PEARL recognized standard of comparing the test results of each pole and ensuring that they are within 50% of each other.

2.3.4 The test results must be within the guidelines recommended in order for the product to become a PEARL labeled product.

PEARL Reconditioning Standards			
MEDIUM VOLTAGE AIR DISCONNECT SWITCHES ENCLOSED MANUALLY OPERATED NON-FUSIBLE	Revision		
	Standard	Number	Date
	2110	5	11-2008

IV PEARL CERTIFICATION

This product has now been reconditioned under the PEARL Reconditioning Standard. The blue PEARL Reconditioning Quality Seal may now be placed on the device.