

PEARL Reconditioning Standards			
LOW VOLTAGE DISCONNECT SWITCHES MANUAL TRIP POWER NON-FUSIBLE	Revision		
	Section	Number	Date
	1130	3	2-11-03

The term "reconditioning" is defined as "the process of returning electrical equipment to safe and reliable operating condition based upon the design of the original manufacturer at the time of manufacturing."

NOTE: This standard pertains disconnects that are typically found as service entrance disconnects or feeder disconnects that provide power to other downstream panelboard, switchboard or equipment. Some of examples of these disconnects are Boltswitch, Bolt-Loc, BP Switch, General Electric THPC and Pringle.

I TEST EQUIPMENT

The following test equipment is required to perform the testing requirements of this reconditioning standard:

1. Insulation Resistance Test Set (Megohmmeter) 1000 Vdc minimum

One of the following pieces of test equipment is required to perform the contact resistance testing requirements of this reconditioning standard:

1. Digital Low Resistance Ohmmeter (DLRO - 10 amp unit is sufficient.)
2. DC Current Source and a Millivoltmeter

PEARL Reconditioning Standards			
LOW VOLTAGE DISCONNECT SWITCHES MANUAL TRIP POWER NON-FUSIBLE	Revision		
	Section	Number	Date
	1130	3	2-11-03

II RECONDITION EVALUATION

These steps are used to determine what will be required to recondition this product under this standard.

1 INSPECTION

1.1 Frame/Enclosure

- 1.1.1 Ensure that the nameplate/label data is legible.
- 1.1.2 Ensure that the third party listing service label is legible.
- 1.1.3 Inspect the overall frame/enclosure for missing screws, bolts, nuts, fasteners, retainers and keepers.
- 1.1.4 Inspect for rust and corrosion.
- 1.1.5 Inspect insulation structure for signs of overheating and deterioration.
- 1.1.6 Record results on appropriate PEARL Inspection and Test Form

1.2 Operating Mechanism

- 1.2.1 Inspect for signs of rust and corrosion.
- 1.2.2 Inspect for excessive and inappropriate lubrication.
- 1.2.3 Inspect for missing screws, bolts, nuts, fasteners, retainers and keepers.
- 1.2.4 Manually operate disconnect switch a minimum of three (3) times while checking for proper operation of the quick-make and quick-break feature.
- 1.2.5 Record results on appropriate PEARL Inspection and Test Form.

1.3 Interphase Barriers

- 1.3.1 Inspect for dust, dirt and foreign materials.
- 1.3.2 Inspect for chips, cracks and deterioration.
- 1.3.3 Inspect for overheating.
- 1.3.4 Record results on appropriate PEARL Inspection and Test Form.

1.4 Arc Extinguishers

- 1.4.1 Inspect for loose and missing parts.
- 1.4.2 Inspect for dust, dirt, foreign material, cracks, chips and signs of overheating.
- 1.4.3 Inspect for excessive deterioration and carbon buildup on the metal separator.
- 1.4.4 Inspect arc runners for excessive deterioration.
- 1.4.5 Record results on appropriate PEARL Inspection and Test Form.

1.5 Arcing Contacts

- 1.5.1 Inspect for excessive deterioration.
- 1.5.2 Inspect for cracks, chips and pitting.
- 1.5.3 Check for proper alignment/seating in the closed position.
- 1.5.4 Record results on appropriate PEARL Inspection and Test Form.

PEARL Reconditioning Standards			
LOW VOLTAGE DISCONNECT SWITCHES MANUAL TRIP POWER NON-FUSIBLE	Revision		
	Section	Number	Date
	1130	3	2-11-03

1.6 Main Contacts

- 1.6.1 Inspect for excessive deterioration.
- 1.6.2 Inspect for cracks, chips and pitting.
- 1.6.3 Check for proper alignment/seating in the closed position.
- 1.6.4 Record results on appropriate PEARL Inspection and Test Form.

1.7 Current Carrying Components

- 1.7.1 Inspect line and load connections for signs of overheating.
- 1.7.2 Inspect line and load connections for missing and defective parts.
- 1.7.3 Inspect hinge/pivot joints for signs of overheating.
- 1.7.4 Inspect hinge/pivot joints for missing and defective parts.
- 1.7.5 Inspect any other current carrying components for signs of overheating.
- 1.7.6 Inspect any other current carrying components for missing and defective parts.

1.8 Interlocks

- 1.8.1 Inspect all interlocks for proper operation.
- 1.8.2 Record results on appropriate PEARL Inspection and Test Form.

PEARL Reconditioning Standards			
LOW VOLTAGE DISCONNECT SWITCHES MANUAL TRIP POWER NON-FUSIBLE	Revision		
	Section	Number	Date
	1130	3	2-11-03

2 TESTING

2.1 Insulation Resistance

2.1.1 Perform an insulation resistance test at test values specified in Table 2 of Section 6000 as follows:

2.1.1.1 Switch in the open position

2.1.1.1.1 Line to load

2.1.1.2 Switch in the closed position

2.1.1.2.1 Phase to phase

2.1.1.2.2 Phase to frame/enclosure

2.1.2 Correct for temperature, if necessary (Table 11).

2.1.3 Record results on appropriate PEARL Inspection and Test Form.

2.1.4 Compare test results to manufacturer's recommendations or Table 2 of Section 6000.

2.2 Contact Resistance

2.2.1 Perform a contact resistance, millivolt drop test or watt-loss test from line to load on each phase of a closed switch with the test points at the line and load lug landings.

2.2.2 Record results on appropriate PEARL Inspection and Test Form.

2.2.3 Compare test results to manufacturer's recommendations.

2.2.4 A PEARL recognized method is comparing the test results of each pole. Results should be within 50% for any of the poles. Any industrial standard used shall provide at least the same integrity as the PEARL recognized standard of comparing the test results of each pole and ensuring that they are within 50% of each other.

PEARL Reconditioning Standards			
LOW VOLTAGE DISCONNECT SWITCHES MANUAL TRIP POWER NON-FUSIBLE	Revision		
	Section	Number	Date
	1130	3	2-11-03

III RECONDITION PROCEDURES

The following procedures are in a recommended order and are required to recondition this product. PEARL recognizes that, based upon actual product design and/or as found condition, some of these procedures may not be applicable. The testing requirement must be completed before the product can be labeled as a PEARL reconditioned product.

1 RECONDITIONING

1.1 Frame/Enclosure

- 1.1.1 Disassemble to clean.
- 1.1.2 Clean all parts of contamination and corrosion,
- 1.1.3 Prepare the product to paint, as necessary.
- 1.1.4 Paint product.

1.2 Missing or Defective Components, Parts and Hardware

- 1.2.1 Replace or repair any missing or defective components, parts and hardware found during the inspection phase of this standard.

1.3 Operating Mechanism

- 1.3.1 Disassemble operating mechanism, as necessary.
- 1.3.2 Clean mechanism.
- 1.3.3 Replace any defective parts.
- 1.3.4 Replate operating mechanism parts, as necessary.
- 1.3.5 Assemble operating mechanism.
- 1.3.6 Apply proper lubrication.
- 1.3.7 Manually operate switch a minimum of three (3) times while checking for proper operation of the quick-make and quick-break feature.

1.4 Arc Extinguishers

- 1.4.1 Remove arc extinguishers.
- 1.4.2 Clean arc extinguishers.
- 1.4.3 Replace any defective arc extinguishers.
- 1.4.4 Assemble arc extinguishers.

1.5 Arcing Contacts

- 1.5.1 Remove and replace any defective arcing contacts.
- 1.5.2 Stationary arcing contacts.
 - 1.5.2.1 Clean and dress.
 - 1.5.2.2 Remove and replate, as necessary.
 - 1.5.2.3 Replace contacts.
- 1.5.3 Movable arcing contacts.
 - 1.5.3.1 Clean and dress.
 - 1.5.3.2 Remove and replate, as necessary.
 - 1.5.3.3 Replace contacts.
- 1.5.4 Check for proper wipe and alignment.
- 1.5.5 Check for proper torque on connections.

PEARL Reconditioning Standards			
LOW VOLTAGE DISCONNECT SWITCHES MANUAL TRIP POWER NON-FUSIBLE	Revision		
	Section	Number	Date
	1130	3	2-11-03

- 1.6 Main Contacts**
 - 1.6.1** Remove and replace any defective main contacts.
 - 1.6.2** Stationary main contacts.
 - 1.6.2.1** Clean and dress.
 - 1.6.2.2** Remove and replate, as necessary.
 - 1.6.2.3** Replace contacts.
 - 1.6.3** Movable main contacts.
 - 1.6.3.1** Clean and dress.
 - 1.6.3.2** Remove and replate, as necessary.
 - 1.6.3.3** Replace contacts.
 - 1.6.4** Check for proper wipe and alignment.
 - 1.6.5** Check for proper torque on connections.
- 1.7 Current Carrying Components**
 - 1.7.1** Line and load connections.
 - 1.7.1.1** Clean and degrease.
 - 1.7.1.2** Replate, as necessary.
 - 1.7.2** Hinge/pivot joints.
 - 1.7.2.1** Clean and degrease.
 - 1.7.2.2** Replate, as necessary.
 - 1.7.3** Other current carrying components.
 - 1.7.3.1** Clean and degrease.
 - 1.7.3.2** Replate, as necessary.
- 1.8 Checks and adjustments**
 - 1.8.1** Check arcing contacts for proper wipe, pressure and gap.
 - 1.8.2** Check main contacts for proper wipe, pressure and gap.
 - 1.8.3** Make all adjustments per manufacturer's instructions. In the absence of a manufacturer's instructions, these adjustments will be based upon procedures that will ensure the original manufacturer's design.
- 1.9 Torque**
 - 1.9.1** Check all screw and bolt connections for the proper torque per manufacturer's recommendations or Table 1 of Section 6000.
 - 1.9.2** Record results on appropriate PEARL Inspection and Test Form.
- 1.10 Final Assembly**
 - 1.10.1** Ensure that the frame/enclosure is plumb and square.
 - 1.10.2** Cover any unused openings.
 - 1.10.3** Ensure that the nameplate/label data is complete, correct and legible.

PEARL Reconditioning Standards			
LOW VOLTAGE DISCONNECT SWITCHES MANUAL TRIP POWER NON-FUSIBLE	Revision		
	Section	Number	Date
	1130	3	2-11-03

2 TESTING

2.1 Insulation Resistance

2.1.1 Perform an insulation resistance at test values specified in Table 2 of Section 6000 as follows:

2.1.1.1 Switch in the open position

2.1.1.1.1 Line to load

2.1.1.1.2 Line to frame/enclosure

2.1.1.1.3 Load to frame/enclosure

2.1.1.1.4 Phase to phase on line side

2.1.1.1.5 Phase to phase on load side

2.1.1.2 Switch in the closed position

2.1.1.2.1 Phase to Phase

2.1.1.2.2 Phase to Frame/enclosure

2.1.1.3 Correct for temperature, if necessary (Table 11).

2.1.1.4 Record results on appropriate PEARL Inspection and Test Form.

2.1.1.5 Compare results to manufacturer's recommendations or Table 2 of Section 6000.

2.1.1.6 The test results must be within the guidelines recommended in order for the product to become a PEARL labeled product.

2.2 Contact Resistance

2.2.1 Perform a contact resistance, millivolt drop test or watt-loss test from line to load on each phase of a closed switch with the test points at the line and load lug landings.

2.2.2 Record results on appropriate PEARL Inspection and Test Form.

2.2.3 Compare test results to manufacturer's recommendations.

2.2.4 A PEARL recognized method is comparing the test results of each pole. Results should be within 50% for any of the poles. Any industrial standard used shall provide at least the same integrity as the PEARL recognized standard of comparing the test results of each pole and ensuring that they are within 50% of each other.

2.2.5 The test results must be within the guidelines recommended in order for the product to become a PEARL labeled product.

IV PEARL CERTIFICATION

This product has now been reconditioned under the PEARL Reconditioning Standard. The PEARL label and/or seal may be placed on it.